



Rough Trax

A GREAT DEAL BETTER

Caster Correction Bush Kit - Fitting Instructions

This template is provided with each caster correction bush kit for the **80 Series Land Cruiser**.

Use the template against the arm to mark the position of the bush offset.

Sleeve offsets should be closest to the arrows at the top of the front hole and the bottom of the rear hole to increase positive castor.

For correct fitment the **distance between** the absolute **centre of the bush** sleeves should be **185mm**.

Fitment is the same for both left and right arms.

***Please Note.** This template may not be the same when printed.*

