

Instructions

Front Differential Drop

N.B: This instruction sheet should be used in conjunction with the workshop manual and proper safety procedures followed.

Install Guide

1. Raise vehicle evenly and safely support.

Note - you possibly can access front Diff mounts without lifting vehicle - Depending on vehicle height.


2. Proceed by removing front bash plate.
3. Using a Jack, support the Diff, then remove the 2x front mount bolts - slowly lower Diff
4. Place 2x 25mm spacers in position - refer image below. Use supplied new flat washers and bolts/nuts - tighten.
5. Re-fit Bash plate with 4x spacers - tightened supplied M8 bolts and spring washers.

Application - Toyota Prado - 120 150


(Refer current catalogue for complete listing)

Contents - Diff spacers x 2

- Bash plate spacers x 4
- M12 bolts x 2
- M12 nyloc nuts x 2
- Flat washers x 4
- M8 bolts x 4
- Spring washers x 4



Front aluminium spacers



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.